## Thermolok <sup>™</sup> Loose-Fill Insulation • 100% Borate Cellulose Insulation • Coverage Chart Thermal • Air Infiltration • Sound • Fire • Protection



Thermolok<sup>™</sup> cellulose insulation is made from recycled paper combined with 100% boron, producing the greenest as well as the safest insulation on the market. Cellulose naturally resists the change of temperature, helps to preserve wood framing, combats fungicides and contains no potentially harmful chemicals.

REV011414

Horizontal Open Blow											
			Maximum Net Coverage			2x4 Joists 16" OC	2x4 Joists 24" OC	2x6 Joists 16" OC	2x6 Joists 24" OC		
R-Value	Initial installed thickness (in.)	Min. settled thickness (in.)	Min. wt. Ib/sq. ft.	Maximum Sq ft /bag		Minimum bags/1000 Sq ft					
13	4.3	3.8	0.35	72.3	13.8	12.7	13.0	12.5	13.0		
19	6.0	5.4	0.57	44.0	22.7	21.3	21.8	20.6	21.3		
22	6.8	6.2	0.68	36.7	27.3	25.8	26.3	25.0	25.7		
30	9.2	8.3	0.99	25.4	39.4	37.9	38.4	37.0	37.8		
38	11.5	10.4	1.29	19.3	51.7	50.1	50.6	49.1	50.0		
40	12.1	10.9	1.37	18.3	54.8	53.1	53.7	52.2	53.0		
49	14.8	13.3	1.71	14.6	68.6	66.9	67.4	65.9	66.8		
60	18.0	16.2	2.14	11.7	85.5	83.8	84.3	82.8	83.7		
Walls @ 2.7 pcf											
13	2x4	3.5	0.79	31.6	31.6	28.6	29.6				
21	2x6	5.5	1.24	20.2	49.5			44.9	46.4		

COVERAGES ARE BASED ON ACTUAL FIELD TEST DATA • BAG WEIGHT - 25 LBS/11.34 KG • DENSITY 1.6 LBS/CU. FT. • THERMAL RESISTANCE 3.7 R/IN.

## **READ THIS BEFORE YOU BUY**

What you should know about R-values

This chart shows the R-value of this insulation. R means resistance to heat flow.

The higher the R-value, the greater the insulating power. Compare insulation R-values before you buy.

The amount of insulation you need depends upon the climate, the type and size of your home, the amount of insulation already in your home, your fuel use patterns and your family size. If you buy too much insulation, it will cost you more than what you'll save in fuel. The initial installed thickness is a guide only and will vary depending on the blowing machine, hose length, applicant, and conditions at the time of installation.

To get the marked R-value, it is essential that the insulation be installed properly.

Coverage chart is based on the settled thickness and is for estimating purposes only. The above calculations are based on progressive density. The initial installed thickness was obtained using a Krendl 500 blowing machine. The machine settings are not adjustable. Actual coverage will be influenced by job conditions and application techniques and may vary as much as 10% without significantly affecting the stated R-value. Regardless of initial thickness, you must use the number of bags required to achieve the proper R-value.

## Installation Certificate

*Thermolok*  $^{\text{m}}$  Loose-Fill Insulation has been installed with the manufacturer's recommendations to provide a value of R-\_\_\_\_\_ using \_\_\_\_\_\_ bags of insulation to cover \_\_\_\_\_\_ square feet of area at a thickness of \_\_\_\_\_\_ inches.

Building Address			
<u> </u>	(Street)	(City, State)	(Zip code)
Installation Co Name			
		(City, State)	(Zip code)
Signature of Installer		Installation Date	
			A RED



## Hamilton Manufacturing, Inc.

901 Russet Street • Twin Falls, ID 83301 USA Office: (208) 733-9689 • Fax: (208) 733-9447 • Email: info@hmi-mfg.com Order desk: 800-777-9689 • Web: www.hmi-mfg.com EPA Registered No. 44757-4 • EPA Est. No. 65049-ID-1 ASTM C739 • ASTM E84 Acute Toxicity Study R&D Services No. RDS-LF9291, RDS-LF9298

We've Got You Covered